High-Performance Office Laminator

Titan™ A3



GB Please read these instructions before use.

F Lire ces instructions avant utilisation.

E Lea estas instrucciones antes de usar la máquina.

D Diese Anleitungen vor Gebrauch genau durchlesen.

I Primo dell'uso, si raccomanda di leggere questo manuale di istruzioni.

NL Gaarne deze instructies eerst te lezen voordat u de machine in gebruik neemt.

S Läs dessa anvisningar innan du använder apparaten.

DK Læs venligst denne vejledning før anvendelse.

FIN Lue nämä ohjeet ennen käyttöä.

N Vennligst les nøye igjennom denne bruksanvisningen før bruk.

PL Przed użyciem proszę zapoznać się z tą instrukcją.

RU Перед эксплуатацией устройства ознакомьтесь с содержанием данной инструкции.

GR *Διαβάστε τις παρακάτω οδηγίες πριν από τη χρήση.*

TR Kullanmadan önce lutfen bu talimatlari okuyen.

CZ Pred použitím si pročtěte tyto pokyny.

SK Pred použitím si prečítajte tieto pokyny.

H Kérjük, hogy használat elött olvassa el az utasításokat.

P Leia estas instruções antes da utilização.

fellowes.com

404415_2_EUR_Titan_All_v3.0.indd 5 25/09/2009 09:21:04

INDEX

LAMINATOR CONTROLS / QUICK START GUIDE	3
ENGLISH	4-9
FRANCAIS	10-15
ESPAÑOL	16-21
DEUTSCH	22-27
ITALIANO	28-33
NEDERLANDS	34-39
SVENSKA	40-45
DANSK	46-51
SUOMI	52-57
NORSK	58-63
POLSKI	64-69
РУССКИЙ	70-75
ΕΛΛΗΝΙΚΑ	76-81
TÜRKÇE	82-87
ČESKY	88-93
SLOVENSKY	94-99
MAGYAR	100-105
PORTUGUÊS	106-111

LAMINATOR CONTROLS



QUICK START GUIDE

SETTING UP THE LAMINATOR

1



2



3



4



STEPS TO LAMINATE

5



6

7

8

9



10



11



12

404415_2_EUR_Titan_All_v3.0.indd 7 25/09/2009 09:21:11

ENGLISH GB

CAPABILITIES

Performance

Format	A3
Entry width	317mm
Estimated heat-up time	4 minutes
Cool down time	30-60 minutes
Lamination speed	variable - max. 90cm/min
Laminating mechanism	Belt-drive
Ready indication	Light & beep
Easi-Access open mechanism	Yes
HeatGuard™ technology	Yes
Clear Path	Yes
Auto shut-off	Yes (30 mins)
Photo-capable	Yes
Carrier-free	Yes

Technical Data

Voltage / Frequency / Current(Amps)	220-240V AC, 50/60Hz, 5.0A
Wattage	1200 Watts
Dimensions (WxDxH)	634 x 215 x 159mm
Net weight	10 kg
Laminating capacity (max thickness)	1mm
Min pouch thickness	75 micron (total thickness = 2 x 75 = 150 micron)
Max pouch thickness	250 micron (total thickness = 2 x 250 = 500 micron)

IMPORTANT SAFETY INSTRUCTIONS

CAUTION:

Please read before use and keep for future reference.

When laminating;

- plug the machine into an easily accessible mains socket.
- to prevent electrical shock - do not use the appliance close to water, do not spill water on to the appliance, power cord or mains socket.

DO ensure the machine is on a stable surface.

DO test laminate scrap sheets before final laminations.

DO remove staples and other metal articles prior to laminating.

DO keep the machine away from heat and water sources.

DO turn off the machine after each use.

DO unplug the machine when not in use for an extended period.

DO use pouches designed for use at the appropriate settings.

DO keep away from pets, while in use.

DO only use Fellowes Roller Wipes (item #57037) for internal cleaning.

DO NOT use appliance if the power cord is damaged.

DO NOT attempt to open or otherwise repair the machine beyond the Easi-Access functions.

DO NOT exceed the machines quoted performance.

DO NOT allow children to use this machine without adult supervision.

DO NOT laminate sharp or metal objects (eg: staples, paper clips).

DO NOT laminate heat-sensitive documents (eg: tickets, ultrasounds etc).

DO NOT laminate with self-adhesive pouches (which require a cold setting).

DO NOT laminate an empty pouch.

DO NOT use sharp objects to clean laminator.

404415_2_EUR_Titan_All_v3.0.indd 4 25/09/2009 09:21:11

LAMINATOR CONTROLS

A	Easi-Access opening cover	G	Selection buttons (up/down/left/right)
B	Adjustable document entry guide	H	Select / OK button
C	Entry support shelf	I	Detachable document exit tray
D	Reverse button	J	On/off switch (at rear)
E	Standby button	K	Carry points (at sides)
F	LED user interface		

FEATURES & TIPS

Titan operates at a fixed temperature. The user only needs to select the required pouch setting before laminating. There is no need to wait for the machine to warm-up or cool-down when switching between thick or thin pouch settings. Once the laminator has reached normal operating temperature, simply select the pouch thickness required and laminate immediately.

FEATURES

'Hot Swap' function.
The Hot Swap function enables the user to instantly switch between thick and thin pouch settings without any processing delays.

Easi-Access open mechanism
The Easi-Access mechanism allows to safely and easily open the laminator for cleaning and maintenance.

HeatGuard™ technology
Keeps the laminator surface up to 50% cooler and makes it more energy efficient then comparable laminators.

'Safe Start' function
When switched on, the machine has a default 'Safe Start' function which is set to the 75 micron setting. You may select other temperature settings as required.

Power Save
The Auto shut-down switches the machine off if it hasn't been used for 30mins to save energy.

To return to the "Home" Menu at any stage, press the "Left/back" key on the navigation buttons.

TIPS

- Always put item into the appropriate sized pouch.
- Always test laminate with a similar size and thickness before final process.
- If required, trim excess material from around the item after lamination and cooling.
- For best results, use Fellowes® brand laminating pouches: Enhance 80, Impress 100, Capture 125, Protect 175, Preserve 250
- When working with different pouch thickness' (temperature settings) it is recommended to start first with the thinnest pouches.
- Prepare pouch and item for lamination. Place item within pouch centred and touching the leading sealed edge. Ensure the pouch is not too large for the item.
- Please read these instructions before use.

404415_2_EUR_Titan_All_v3.0.indd 5 25/09/2009 09:21:12

SETTING UP THE LAMINATOR

1. Ensure the machine is on a stable surface. Check there is enough clear space (min 50cm) behind the machine to allow items to pass through freely.

2. Select the correct power lead for the appropriate power supply. Fit the lead to the machine (the socket is at the rear of the machine).

3. Plug the machine into an easily accessible mains socket. Switch the mains supply on.

4. To fully support pouches and items of different sizes please use the adjustable entry guide to centre the item before laminating. Place exit tray onto the rear of the machine.

STEPS TO LAMINATE

5. Switch the power on (Power switch located at the rear of the machine).

6. Select the 'Standby' button on the control panel. Check the LED controls turn on. The 75 micron and ready LED's will flash for 5 seconds before automatically selecting the 75 micron heat setting. Any setting can be selected at any time as required. To open the machine, it is normal for the machine to cool before opening. The LED interface allows selection of these functions:
   - 75,100,125,175,250 micron pouch settings
   - Manual laminating
   - Reverse
   - 'Easi-access' to service the mechanism

7. The laminator will automatically select the thinnest pouch setting (75 micron) within 5 seconds of power-on unless another setting is selected. During warm-up or warm-down, the selected pouch setting will flash red.

8. When the laminator has reached the chosen setting, the LED will stop flashing and glow red. The machine will sound 2 short alerts.

9. Place item into open pouch. Ensure the item is centred against the sealed front edge. Use the appropriate pouch size for the item.

10. Place the pouch, sealed edge first into the document entry. Keep the pouch straight and central within the document entry, not on an angle. Use the entry markings as a guide.

11. Upon exit, the laminated pouch is hot and soft. Take care and remove the pouch immediately. Place the pouch onto a flat surface to cool. This helps prevent any jamming.

12. To reverse the laminating process at any stage, press and hold the 'Reverse' button to eject the item. The laminator will sound alerts continuously and the ready LED will flash.

NEED HELP?



Let our experts help you with a solution.

Customer Service: **www.fellowes.com**

Help Line Europe: 00-800-1810-1810

404415_2_EUR_Titan_All_v3.0.indd 6 25/09/2009 09:21:14

MAINTENANCE - Easi-Access™

The Titan laminator can be opened manually by selecting the 'open' setting ( ) on the control panel.
Please note: the power supply and the machine must both be **ON** to release the electronic safety catch.

Select the 'open' setting ( ) using the navigation buttons on the control panel. Press 'OK' button.

The ready LED will flash and the machine will cool down. This may take between 30-60 minutes.

When the machine has cooled to a safe temperature, the ready LED will stop flashing and an alert will sound.



To open the top cover, move the levers on each side of the machine backwards to release the electronic safety catch.



Lift the top cover with both hands. You will see the laminating engine and belt-drive mechanism.



To open the belt-drive mechanism, Pull the 2 cam levers forwards, on each side of the mechanism. The upper carriage can now be lifted upwards from the front. Lift the carriage and open fully until it stops in the rest position.



Take care when cleaning any residue from the rollers. Fellowes laminator wipes (CRC# 57037) are recommended.



IMPORTANT:
When closing the mechanism, ensure the 2 cam levers are both pushed forwards to lock the belt-drive carriage correctly in position. The lid can be closed when the carriage is correctly locked.

ADJUSTABLE ENTRY GUIDE



The Entry Guide can be manually adjusted (especially for smaller documents) to ensure the items are best supported when inserted and helps avoid mis-feeds.

INTEGRATED CARRY POINTS

The Titan laminator has integrated carry points for safe and easy movement of the laminator – push in the flaps on both ends of the laminator to get to them.

404415_2_EUR_Titan_All_v3.0.indd 7 25/09/2009 09:21:19

WORLDWIDE WARRANTY

Fellowes warrants all parts of the laminator to be free of defects in material and workmanship for 2 years from the date of purchase by the original consumer. If any part is found to be defective during warranty period, your sole and exclusive remedy will be repair or replacement, at Fellowes' option and expense, of the defective part. This warranty does not apply in cases of abuse, mishandling or unauthorised repair. Any implied warranty, including that of merchantability or fitness for particular purpose, is hereby limited in duration to the appropriate warranty period set forth above. In no event shall Fellowes be liable for any consequential damages attributable to this product. This warranty gives you specific legal rights. You may have other legal rights that vary from this warranty. The duration, terms and conditions of this warranty are valid worldwide, except where different limitations, restrictions or conditions may be required by local law. For more details or to obtain services under this warranty, please contact Fellowes or your dealer.

PRODUCT REGISTRATION

Thank you for purchasing a Fellowes product. Please visit www.fellowes.com/register to register your product and benefit from product news, feedback and offers. Product details can be found listed on the rating plate positioned on the rear side or underside of the machine.

STORAGE & EXTERNAL CLEANING

Switch off the machine at the wall. Allow the machine to cool.
The outside of the machine can be cleaned with a damp cloth. Do not use solvents or flammable materials to polish the machine. Cleaning sheets can be used with the machine. When the machine is warm – run the sheets through the machine to clean any residue off the rollers. For advanced Cleaning of the inside of the laminator, please see the section on the CleanMe function above. Use Fellowes Laminator wipes (#57037) only for the internal cleaning. For optimum performance, it is recommended that cleaning sheets (#53206 / #53207) are used with the machine regularly.

W.E.E.E.

This product is classified as Electrical and Electronic Equipment. Should the time come for you to dispose of this product please ensure that you do so in accordance with the European Waste of Electrical and Electronic Equipment (WEEE) Directive and in compliance with local laws relating to this directive.

For more information on the WEEE Directive please visit www.fellowesinternational.com/WEEE

404415_2_EUR_Titan_All_v3.0.indd 8 25/09/2009 09:21:20

TROUBLESHOOTING

Problem	Possible cause	Solution
No 'red' power on LED	Machine is not switched on	Switch on machine at rear next to plug inlet and at the wall socket
Ready light does not come on after a long period	Machine is in a hot or humid area	Move the machine to a cooler and dry area
Pouch does not completely seal the item	Item may be too thick to laminate	Pass through the machine again
	Temperature setting may be incorrect	Check pouch thickness is correctly selected and pass through again
Pouch has waves or bubbles	Temperature setting may be incorrect	Check pouch thickness is correctly selected and pass through again
Pouch is lost in the machine	Pouch is jammed	Select reverse button and pull out the item by hand. Select the open machine setting and clean the rollers.
Jamming	Pouch was used 'open end' first	
	Pouch was not centered on entry	
	Pouch was not straight upon entry	
	Empty pouch was used	
Pouch is damaged after lamination	Damaged rollers or adhesive on rollers	Pass cleaning sheets through the machine to test and clean rollers. Select the open machine setting and clean the rollers.

404415_2_EUR_Titan_All_v3.0.indd 9 25/09/2009 09:21:20

Declaration of Conformity
Useful Phone Numbers

Declaration of Conformity

Fellowes Manufacturing Company

Yorkshire Way, West Moor Park, Doncaster, South Yorkshire, DN3 3FB, England declares that the model Titan A3 conforms with the requirements of (RoHS) the Restriction of Hazardous Substances Directive 2002/95/EC. The Low Voltage Directive 2006/95/EC as amended by directive 93/68/EEC. The Electromagnetic Compatability Directive 2004/108/EC as amended by directive 92/31/EEC & 96/68/EEC and the following Harmonised European Normes EN standards and IEC standards.

Information Technology Product: EN-60950-1 2006 / IEC-60950-1 2005

EMC: EN-55014-1 : 2006 EN-55014-2 / A1 : 2001 EN-61000-3-2 : 2006 EN-61000-3-3 : 2008

Itasca, Illinois, USA
June 2009

James Fellowes

Help Line

Europe	00-800-1810-1810

Fellowes

Australia	+61-3-8336-9700	Korea	+82-(0)-2-3462-2844
Benelux	+31-(0)-76-523-2090	Malaysia	+60-(0)-35122-1231
Canada	+1-905-475-6320	Polska	+48-(22)-771-47-40
Deutschland	+49-(0)-5131-49770	Russia	+7-(495)-228-14-03
España / Portugal	+ 34 902 33 55 69	Singapore	+65-6221-3811
France	+33-(0)-1-78-64-91-00	United Kingdom	+44-(0)-1302-836836
Italia	+39-71-730041	United States	+1-630-893-1600
Japan	+81-(0)-3-5496-2401		

1789 Norwood Avenue, Itasca, Illinois 60143-1095 • USA • 630-893-1600
fellowes.com

Australia Benelux Canada China Deutschland España France Italia Japan Korea Polska Singapore United Kingdom United States

© 2009 Fellowes, Inc. Part No. 404415-2